Operations Guide - GreaseShield®1000 AST




FOG Container

The extracted FOGs are collected in the FOG storage container. This container must be emptied and cleaned at least once a day including the wiper blade. The Max Fill Line should not be exceeded.



Automated Solids Transfer The Automated Solids Transfer (AST) system extracts any solids waste from the effluent that enters the GreaseShield®. The AST Auger transports the solids waste from the tank and deposits it in the Solids collection container at the rear of the unit. This container must be emptied and cleaned at least once a day.



Automated Self Cleaning

(Additional cleaning cycles can be

added upon request)

Anti-Flood Sensor If the effluent level inside the GreaseShield® becomes to high, a pressure sensor is triggered ctivating a pump. This ump extracts Grey Water rom the bottom of the tank and sent directly to the drain via the normal outlet.

A number of co-operating baffles combined the the reverse flow design of the tank, utilises the difference density of grey water and FOGs to separate the effluent. FOGs are directed towards a large, oleophilic (attracts FOGS) and hydrophobic (repels water), FOG Removal Roller. This submerged Roller removes the FOGs from the effluent. A silicone Wiper Blade, with anti-static properties, scrapes the FOGs from the roller and deposits them into the FOG Container.



V5 29/07/2022